



Select an Item. Read the Selection Code mentioned below the item on the tray.

To check the item price, press the Selected item on the keypad.

Insert Notes – Rs. 10 or 20 Only
OR Flash your Charge Card issued by your company

The Note should NOT be crumbled or folded.
Please insert fully flattened NOTE's only

Do NOT Insert any Coins...

Press Desired Selection Code ... A2, C4, E5 etc.

Collect Your Product from Delivery Door

In case the product fails to dispense, do NOT panic and do NOT push the machine. Please log in your complaint on feedback sheet attached to the machine (left side) and it will be resolved within 24 Hours.

For Enquiry or Complaints –